




B-2538-SM B-2512-SM

B-2538 3/8" AIR RATCHET WRENCH

B-2512 1/2" AIR RATCHET WRENCH



No.	Parts No.	Description	Q'ty
1	B2512M3002-01	Motor Housing	1
2	B2512M3002-02	Valve Stem	1
3	B2512M3002-03	Throttle	1
4	B2512M3002-04	O-Ring	1
5	B2512M3002-05	Pin	1
6	B2512M3002-06	Air Inlet	1
7	B2512M3002-07	Spring	1
8	B2512M3002-08	Lock Pin	1
9	B2512M3002-09	O-Ring	1
10	B2512M3002-10	Valve Plug	1
14	B2512M3002-14	Cap	1
15	B2512M3002-15	Spring	1
16	B2512M3002-16	Throttle Valve	1
17	B2512M3002-17	Valve Seat	1
18	B2512M3002-18	Plastic Grip	1
19	B2512M3002-19	O-Ring	1
20	B2512M3002-20	Exhaust Deflector	1
22	B2512M3002-22	Bearing	1
23	B2512M3002-23	Rear Plate	1
24	B2512M3002-24	Pin	1
25	B2512M3002-25	Rotor Blade	4
26	B2512M3002-26	Rotor	1
27	B2512M3002-27	Cylinder	1
28	B2512M3002-28	Front Plate	1
29	B2512M3002-29	Bearing	1

No.	Parts No.	Description	Q'ty
30	B2512M3002-30	Washer	1
31	B2512M3002-31	Thread Ring Gear	1
32	B2512M3002-32	Gear	3
33	B2512M3002-33	Pin	3
34	B2512M3002-34	Gear Plate	1
35	B2512M3002-35	Locking Nut	1
36	B2512M3002-36	Bushing	1
37	B2512M3002-37	Needle Bearing	1
38	B2512M3002-38	Ratchet Pawl	1
39	B2512M3002-39	Ratchet Housing	1
40	B2512M3002-40	Drive Bushing	1
41	B2512M3002-41	Ratchet Voke	1
42	B2512M3002-42	Reverse Switch	1
43	B2512M3002-43	Spring	2
44	B2512M3002-44	Sleeve	2
45	B2512M3002-45	Washer	1
46	B2538M3003-46	3/8" Ratchet Anvil (Incl. 51,52) [B-2538]	1
	B2512M3002-46	1/2" Ratchet Anvil (Incl. 51,52) [B-2512]	1
47	B2512M3002-47	Pin	2
48	B2512M3002-48	Ratchet Pawl	2
	B2538M3003-49	Washer [B-2538]	1
49	B2512M3002-49	Washer [B-2512]	1
50	B2512M3002-50	Retainer Ring	1
53	B2512M3002-53	Spring	2
54	B2512M3002-54	Steel Ball	2