


D-4130-SM  
AIR BODY SAW



No.	Parts No.	Description	Q'ty
1	D41306611F-01	Valve Screw	1
2	D41306611F-02	O-Ring	1
3	D41306611F-03	O-Ring	1
4	D41306611F-04	Air Controller	1
5	D41306611F-05	Valve Spring	1
6	D41306611F-06	Valve Stem	1
7	D41306611F-07	O-Ring	1
7A	D41306611F-07A	O-Ring	1
8	D41306611F-08	Valve Bushing	1
9	D41306611F-09	Inlet Bushing	1
10	D41306611F-10	Cap Screw	4
11	D41306611F-11	Washer	4
12	D41306611F-12	Lever Pin	1
13	D41306611F-13	Throttle Lever	1
15	D41306611F-15	Valve Case	1
16	D41306611F-16	Bush	1
17	D41306611F-17	Cylinder	1
18	D41306611F-18	Valve Sleeve	1
19	D41306611F-19	Actuate Valve	1
20	D41306611F-20	Washer	1
21	D41306611F-21	Cap Screw	3
22	D41306611F-22	Gasket	1
23	D41306611F-23	Valve Block	1
24	D41306611F-24	Set Screw	2
25	D41306611F-25	Bush	2
26	D41306611F-26	Chuck Cover	1

No.	Parts No.	Description	Q'ty
27	D41306611F-27	Screw	2
28	D41306611F-28	Housing	1
28A	D41306611F-28A	Plastic Wrapp	1
29	D41306611F-29	Piston Ass'y	1
30	D41306611F-30	Set Screw	2
31	D41306611F-31	Service Wrench (2mm)	1
32	D41306611F-32	Guide Plate	1
33	D41306611F-33	Blade Chuck	1
34	D41306611F-34A	Work Guide (Long)	1
	D41306611F-34B	Work Guide (Short)	1
35	D41306611F-35A	Blade (32T)	1
	D41306611F-35B	Blade (24T)	1
36	D41306611F-36	Service Wrench (4mm)	1
38	D41306611F-38	Screw	1
39	D41306611F-39	Upper Wear Shoe	1
40	D41306611F-40	Blade Guide	2
41	D41306611F-41	Bridge	1
42	D41306611F-42	Front Bumper	1
43	D41306611F-43	Rear Bumper	1
44	D41306611F-44	Roll Pin	2
45	D41306611F-45	Spring	1
46	D41306611F-46	Packing	1
47	D41306611F-47	Packing	1
48	D41306611F-48	Packing	1
49	D41306611F-49	Set Screw	1