


A-3138 A-3112

3/8" SQ. DR. SUPER DUTY AIR ANGLE IMPACT WRENCH (JUMBO HAMMER)

1/2" SQ. DR. SUPER DUTY AIR ANGLE IMPACT WRENCH (JUMBO HAMMER)



PARTS LIST

No.	Parts No.	Description	Q'ty
1	A-3112-5245-01	Hammer Case Ass'y [Incl.: 42, 43, 59]	1
2	A-3112-5245-02	Housing	1
3	A-3112-5245-03	Motor Housing	1
4	A-3112-5245-04	Trigger	1
5	A-3112-5245-05	Lock Ring	1
6	A-3112-5245-06A	Air Inlet (PT19)	1
	A-3112-5245-06B	Air Inlet (NPT18)	1
7	A-3112-5245-07	O-Ring	1
8	A-3112-5245-08	Spring	1
10	A-3112-5245-10	Exhaust Deflector	1
11	A-3112-5245-11	Motor Housing	1
12	A-3112-5245-12	Bushing	1
13	A-3112-5245-13	Throttle Valve Plunger	1
14	A-3112-5245-14	O-Ring	1
16	A-3112-5245-16	Spring Pin	1
17	A-3112-5245-17	Reverse Knob	1
18	A-3112-5245-18	Pin	1
19	A-3112-5245-19	Gasket	1
20A	A-3112-5245-20A	Throttle Valve Ass'y [Incl 20-1, 20-2]	1
21	A-3112-5245-21	Screw	4
22	A-3112-5245-22	O-Ring	1
23	A-3112-5245-23	O-Ring	1
24	A-3112-5245-24	Reverse Valve	1
25	A-3112-5245-25	Pin	1
26	A-3112-5245-26	Spring	1
27	A-3112-5245-27	Bearing	1
28	A-3112-5245-28	End Plate	1

No.	Parts No.	Description	Q'ty
29	A-3112-5245-29	Spring Pin	3
30	A-3112-5245-30	Cylinder	1
31	A-3112-5245-31	Rotor Blade	7
32	A-3112-5245-32	Rotor	1
33	A-3112-5245-33	End Plate	1
35	A-3112-5245-35	Bearing	1
36	A-3112-5245-36	Washer	1
37	A-3112-5245-37	Hammer Pin	2
38	A-3112-5245-38	Hammer Frame	1
39	A-3112-5245-39	Hammer	1
40	A-3112-5245-40	Bushing	1
41	A-3112-5245-41	Work Spindle	1
44	A-3112-5245-44	Pin	1
45	A-3112-5245-45	1/2" Ratchet Anvil [Incl.: 09, 51]	1
54	A-3138-5235-54	3/8" Ratchet Anvil [Incl.: 55, 56]	1
46	A-3112-5245-46	Retainer	1
47	A-3112-5245-47	Thrust Washer	1
48	A-3112-5245-48	Retainer	1
49	A-3112-5245-49	O-Ring	1
50	A-3112-5245-50	Throttle Valve Seat	1
52	A-3112-5245-52	O-Ring	1
53	A-3112-5245-53	O-Ring	1
57	A-3112-5245-57	Needle Bearing	1
58	A-3112-5245-58	Screw	2
60	A-3112-5245-60	Gasket	1